
Assembly Instructions Instructions d'assemblage Instrucciones de Ensamblaje

Williams-Sonoma Inc.

Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham

1-September-2021 1/2



EMERSON APPLIANCE PULL

Williams-Sonoma Inc.

Pottery Barn - Pottery Barn Teen - Pottery Barn Kids - Williams Sonoma Home - West Elm - Rejuvenation - Mark and Graham

1-September-2021 2/2

CALIFORNIA PROPOSITION 65 WARNING: This product can expose you to chemicals including Lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.


PARTS INCLUDED

- 1 pc Appliance Pull
- ●2pcs 1/4-20 1" Truss head screw,
- •2pcs 1/4-20 1-1/2" Truss head screw
- ●2pcs 1/4-20 1-3/4" Truss head screw

MOUNTING INSTRUCTIONS

This Pull includes hardware that is designed to mount securely to drawer-fronts or cabinet doors that have a thickness range between 1/2" and 1-1/2" inches. If you drawer- front or door is thicker or thinner than this range, please obtain the appropriate size screw from your local hardware store.

Carefully determine a desired pull location. Use 1/4 inch diameter drill bit and appropriate drill to make the holes through the drawer-front / door with the proper center to center distance matching your pulls. Insert the appropriate length screws from the back of the drawer / door front, Attach the pull onto the protruding threads of the screws. Use a screwdriver to tighten the screws while gently holding the pull.



CLEANING INSTRUCTIONS

- 1. Dust often using a clean, soft, dry and lint-free cloth.
- 2. Blot spills and wipe with a clean, damp cloth immediately.
- 3. We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- 4. Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary

© 2021 Williams-Sonoma, Inc.